

Liebert HPM range: Air flow Patterns

Downflow

Blow into raised floor



Upflow

Connected to ceiling ducts



Displacement

Free air distribution



Upflow with front air discharge

No need of ducts

